

SERVICE MANUAL

**S30 SUPPLEMENT CHASSIS MANUAL
DATSUN 240-Z SPORTS**

*NATIONAL
SERVICE
TRAINING
DEPARTMENT*



NISSAN MOTOR CORP. IN U.S.A.

GARDENA, CALIFORNIA

SERVICE MANUAL

**S30 SUPPLEMENT CHASSIS MANUAL
DATSUN 240-Z SPORTS**



NISSAN MOTOR CORP. IN U.S.A.

GARDENA, CALIFORNIA

FOREWORD

This supplement as prepared by the National Service Training Department contains important service information in addition to and/or superseding the basic "Service Manual" 240Z, Chassis and Body (Part No. 99999-20016).

More comprehensive instructions are provided for servicing the dash area including removal and replacement (R&R) of the instrument panel assembly

and floor console (Automatic and Standard transmission models). Additionally, the "heat and ventilating system" is fully documented in this supplement, as well as R&R of the center instruments, center console finisher, and radio. Section VI contains a revised wiring diagram and illustrations for positive identification of wire harness electrical connectors.

TABLE OF CONTENTS

Section	Page
I INSTRUMENT PANEL — DESCRIPTION	1
A. Preparation for Removal (Instrument Panel Component Disconnect)	3
B. Removal (Instrument Panel Assembly)	3
C. Replace (Instrument Panel and Components)	5
II FLOOR CONSOLE — DESCRIPTION	7
A. Removal	7
B. Remove and Replace (Floor Console Electrical)	9
III HEAT AND VENTILATING SYSTEM (HVS) — DESCRIPTION	11
A. Removal (Compartment Air Intake/Blower Assembly)	11
B. Removal (Instrument Panel, Center Console Finisher)	14
C. Removal (Heating Unit Assembly)	15
D. Replace (Heat and Ventilating System Components)	16
E. Bench Service (Heating Unit)	17
IV CENTER GROUP PANEL INSTRUMENTS AND LIGHTING CONTROL — DESCRIPTION	19
A. Remove and Replace (Ammeter/Fuel Gauge, Water Temp/Oil Pressure Gauge, Clock)	19
B. Remove and Replace, Instrument Panel Lighting, Illumination Control (Rheostat)	20
V RADIO AND COMPONENTS — DESCRIPTION	21
A. Remove and Replace (Radio Receiver/Tuner)	21
B. Remove and Replace (Radio Speaker and Power Antenna)	23
VI ELECTRICAL	25

LIST OF ILLUSTRATIONS

Figure	Title	Page
I-1	Instrument Panel Assembly	1
I-2	Instrument Panel, Wire Harness Disconnect	2
I-3	Right-Hand Instrument Panel Floor Attach Points (LH Opposite)	3
I-4	Instrument Panel Attaching Hardware (Exploded View)	4
II-1	Floor Console and Attaching Hardware (Exploded View)	8
III-1	Heat and Ventilating System (HVS) Installation	12
III-2	Heat and Ventilating System (Exploded View)	13
III-3	Removal of Blower Motor/Fan Assembly	14
III-4	Air Intake/Blower Assembly Cable Disconnect	14
III-5	Removing Air Intake/Blower Assembly	14
III-6	Heater Control Cable Disconnect (LH)	14
III-7	Heater Control Cable Disconnect (RH)	15
III-8	Method of Draining Heater Core With Air Pressure	15
III-9	Air Box Ventilator (Console Finisher Removed)	16
III-10	Removing Heater Assembly	16
III-11	Heater Hose and Valve Assembly	17
III-12	Removing Heater End Plate	18
III-13	Removing Heater Core	18
IV-1	Center Group Instruments	19
IV-2	Removal of Glove Compartment Liner	19
IV-3	Removal of Instrument Panel Illumination Control (Rheostat)	20
V-1	Radio Chassis Rear Mount	21
V-2	Radio Tuner Mounting Screws	21
V-3	Radio Installation and Components	22
V-4	Speaker and Antenna Installation (Interior Trim Panels Removed)	23
V-5	Speaker and Bracket Installed	23
VI-1	Instrument Panel Wire Harness (Single Connector Function and Color Identification)	26
VI-2	Instrument Panel, Electrical Harness (Major Connector Identification)	28
VI-3	Engine Compartment, Electrical Harness (Major Connector Identification)	29
VI-4	Body Electrical Harness (Major Connector Identification)	30
VI-5	Wiring Diagram (Basic Model S30 Series for U.S.A.)	31
VI-6	Wiring Diagram (Late Model S30 Series for U.S.A.)	33